


Getting Started


Logging In

When you start up your Cleartouch, you will be presented with a few options to log in. As of the writing of this article, you will log in as Admin. All Admin PIN codes should be the same, six zeros: 000000



The Guest login is for any other user that is not a teacher. For example, after school programs can log in as a guest and not interfere with the classroom teacher's accounts.

If you see this screen:



Don't be alarmed. The Cleartouch likely has internet connection, but the service that it connects to that tells if it is online or not is probably blocked by a filter. You should be able to log in and use the device anyway.

Revision #3

Created 28 August 2026 18:20:45 by c

Updated 28 August 2026 19:47:28 by c